



**GURU NANAK DEV ENGINEERING COLLEGE, BIDAR  
DEPARTMENT OF APPLIED SCIENCES & HUMANITIES**

# **APPLIED PHYSICS NOTES FOR CSE STREAM (2022 SCHEME)**



# Contents

## **I MODULE 1 : LASER AND OPTICAL FIBERS**

### **1 LASER**

- 1.1 Introduction . . . . .
- 1.2 Characteristics of a LASER beam . . . . .
- 1.3 Interaction of radiation with matter . . . . .
  - 1.3.1 Induced Absorption . . . . .
  - 1.3.2 Spontaneous Emission . . . . .
  - 1.3.3 Stimulated Emission . . . . .
- 1.4 Einstein's A and B co-efficients and expression for energy d . . . . .
- 1.5 LASER Action and the Conditions for LASER action . . . . .
  - 1.5.1 Population Inversion and Pumping . . . . .
  - 1.5.2 meta-stable state . . . . .
- 1.6 Requisites of a LASER system . . . . .
  - 1.6.1 Energy Source or Pumping Mechanism . . . . .
  - 1.6.2 Active medium . . . . .
  - 1.6.3 Resonant cavity (or) LASER cavity . . . . .
- 1.7 Semiconductor LASER or Diode LASER . . . . .
- 1.8 Applications of LASER . . . . .
  - 1.8.1 LASER Barcode Reader . . . . .
  - 1.8.2 LASER Printer . . . . .
  - 1.8.3 LASER Cooling . . . . .
- 1.9 Model Questions . . . . .
- 1.10 Numerical Problems . . . . .

### **2 Optical Fibers**

- 2.1 Introduction . . . . .
- 2.2 Total Internal Reflection . . . . .
- 2.3 Angle of acceptance and Numerical aperture . . . . .
  - 2.3.1 Condition for propagation . . . . .
- 2.4 Modes of propagation . . . . .
- 2.5 RI Profile . . . . .
  - 2.5.1 Types of optical fibers . . . . .
- 2.6 Attenuation . . . . .
  - 2.6.1 Absorption loss . . . . .
  - 2.6.2 Scattering loss . . . . .
  - 2.6.3 Geometric effects . . . . .
- 2.7 Applications of Optical Fibers . . . . .
  - 2.7.1 Fiber Optic Networking . . . . .
  - 2.7.2 Point to point communication using Optical Fibers . . . . .
- 2.8 Model Questions . . . . .
- 2.9 Numerical Problems . . . . .



## Chapter 1

# LASER

### 1.1 Introduction

**LASER** is an acronym for Light Amplification by Stimulated Emission of Radiation. The first LASER was built by Theodore H Maiman in the year 1960. Thus it finds various applications starting from industries to communication.

### 1.2 Characteristics of a LASER beam

The LASER beam has the following four characteristics.

1. LASER beam is highly monochromatic.
2. LASER beam is highly coherent.
3. LASER beam is highly directional.
4. LASER is a high intensity beam of light.

### 1.3 Interaction of radiation with matter

The interaction between radiation and matter occurs through the following three processes.

1. Induced absorption
2. Spontaneous emission
3. Stimulated emission

#### 1.3.1 Induced Absorption

When a photon of right energy is incident on the atom then the photon is absorbed. This process is induced by the photon and hence it is called Induced Absorption.

Consider an atom in a lower energy state  $E_1$ , it will excite to higher energy state  $E_2$  by absorbing the incident photon of energy  $E = h\nu = E_2 - E_1$ . Here  $E_1$  energy of the lower energy state,  $E_2$  is the energy of the higher energy state,  $h$  is the Planck's constant  $\nu$  is the frequency of photon.




Figure 1.1: Induced absorption

#### 1.3.2 Spontaneous Emission

Spontaneous emission is the process of emission of photon, when an atom transits from higher energy level to lower energy level without the influence of any external energy.




Figure 1.2: Spontaneous emission

An electron in the higher energy state of an atom makes a transition to lower energy state without the action of any external agency. The energy of the photon emitted is given by  $E = h\nu = E_2 - E_1$ . In this process the emitted photons need not travel in the same direction. Thus the light beam is not directional.



# GURU NANAK DEV ENGINEERING COLLEGE, BIDAR

## DEPARTMENT OF APPLIED SCIENCES & HUMANITIES

### 1.3.3 Stimulated Emission

When a photon of suitable energy interacts with an atom in the higher energy state then the atom is stimulated (Forced) to make transition from higher energy state to a lower energy state with the emission of a photon. Both the incident photon and the emitted photons are coherent and travel in the same direction. Thus the process is called stimulated emission.




Figure 1.3: Stimulated emission

When a photon of energy  $h\nu = E_2 - E_1$  interacts with an atom in the higher energy state the stimulated emission takes place with the emission of two photons of same energy that are highly directional and coherent. Thus stimulated emission could be used to generate a highly coherent directional beam of light.

### 1.4 Einstein's A and B co-efficients and expression for energy density

Consider a system containing  $N$  atoms and is under thermal equilibrium. Let  $E_1$  and  $E_2$  be the lower and higher energy levels that contain  $N_1$  and  $N_2$  number of atoms respectively. Let the incident energy density of the radiation be  $E_\nu$ . Hence the system absorbs and emits the energy through the following processes. The energy of the photons absorbed and emitted by the atoms is  $E = h\nu = (E_2 - E_1)$

#### Rate of induced absorption

The rate of induced absorption is defined as the number of induced absorption per second per unit volume in unit time. Rate of absorption depends on

1. Number of atoms in the lower energy state  $N_1$ .
2. The incident energy density  $E_\nu$ .

Hence

1. Rate of Induced absorption  $\propto N_1 E_\nu$

2. Rate of Induced absorption  $= B_{12} N_1 E_\nu$

Here  $B_{12}$  is proportionality constant called Einsteins coefficient of Induced absorption.

#### Rate of spontaneous emission:

The number of spontaneous emission per unit volume in unit time is called rate of spontaneous emission. Rate of spontaneous emission depends on

Since spontaneous emission is a voluntary process it is independent of energy density  $E_\nu$ . The rate of spontaneous emission depends only on the number of atoms in the higher energy state  $N_2$ . Thus

1. Rate of spontaneous emission  $\propto N_2$
2. Rate of Spontaneous emission  $= A_{21} N_2$

Here  $A_{21}$  is the proportionality constant called Einstein's co-efficient of spontaneous emission.

#### Rate of stimulated emission

The number of stimulated emission per unit volume in unit time is called rate of stimulated emission. Rate of stimulated emission depends upon,

1. Number of atoms in the higher energy state ( $N_2$ )
2. The energy density ( $E_\nu$ ).

Hence

1. The Rate of stimulated emission  $\propto N_2 E_\nu$
2. Rate of stimulated emission  $= B_{21} N_2 E_\nu$

Here the proportionality constant called  $B_{21}$  is Einstein's coefficient of stimulated emission.

Under Thermal Equilibrium the total Energy of the System remains unchanged. Hence Rate of Absorption is equal to rate of emission.

$\therefore$  Rate of Induced Absorption = [Rate of Spontaneous emission + Rate of Stimulated Emission]

$\therefore$

$$B_{12} N_1 E_\nu = A_{21} N_2 + B_{21} N_2 E_\nu \quad (1.1)$$

$$(B_{12} N_1 - B_{21} N_2) E_\nu = A_{21} N_2$$

$$E_\nu = \frac{A_{21} N_2}{B_{12} N_1 - B_{21} N_2} \quad (1.2)$$

$$E_\nu = \frac{A_{21}}{B_{12} \frac{N_1}{N_2} - B_{21}} \quad (1.3)$$

$$E_\nu = \frac{A_{21}}{B_{21}} \left[ \frac{1}{\frac{B_{12}}{B_{21}} \frac{N_1}{N_2} - 1} \right] \quad (1.4)$$

According to Boltzmann relation the we have

$$\frac{N_2}{N_1} = e^{\frac{-h\nu}{kT}} \quad (1.5)$$

or we can re-write as,

$$\frac{N_1}{N_2} = e^{\frac{h\nu}{kT}} \quad (1.6)$$

Here  $h$  is the Planck's constant,  $c$  is the speed of light in vacuum,  $\lambda$  is the wavelength of the photon,  $k$  is the Boltzmann constant and  $T$  is the absolute temperature. Substituting for  $\frac{N_1}{N_2}$  in equation 1.4

$$E_\nu = \frac{A_{21}}{B_{21}} \left[ \frac{1}{\frac{B_{12}}{B_{21}} \left( e^{\frac{h\nu}{kT}} - 1 \right)} \right] \quad (1.7)$$

According to Planck's radiation law, the equation for energy density in the frequency domain is given by

$$E_\nu = \frac{8\pi h\nu^3}{c^3} \left[ \frac{1}{e^{\frac{h\nu}{kT}} - 1} \right] \quad (1.8)$$

on comparing equations 1.7 and 1.8 we can get

$$\frac{A_{21}}{B_{21}} = \frac{8\pi h\nu^3}{c^3} \quad (1.9)$$

and

$$\frac{B_{12}}{B_{21}} = 1 \quad (1.10)$$

or  $B_{12} = B_{21}$

This means that Probability of Induced absorption is equal to Probability of Stimulated emission. Hence  $A_{21}$  &  $B_{21}$  can be replaced by  $A$  &  $B$ . Thus equation 1.7 could be written as

$$E_\nu = \frac{A}{B} \left[ \frac{1}{e^{\frac{h\nu}{kT}} - 1} \right] \quad (1.11)$$

Hence the expression for energy density in terms of Einstein's co-efficient  $A$  and  $B$ .

## 1.5 LASER Action and the Conditions for LASER action

Consider a LASER system. Let an atom in the excited state is stimulated by a photon of right energy so that atom makes stimulated emission. Two coherent photons are obtained. These two coherent photons if stimulate two atoms in the excited state to make emission then four coherent photons are emitted. These four coherent photons stimulate 4 more atoms in the excited state resulting in 8 coherent photons and so on. As the process continues number of coherent photons increases. These coherent photons constitute an intense beam of LASER. This phenomenon of building up of number of coherent photons so as to get an intense LASER beam is called lasing action.




Figure 1.4: LASER action

LASER action could be achieved through the conditions population inversion and meta-stable state.

### 1.5.1 Population Inversion and Pumping

If a system is under thermal equilibrium the number of atoms in excited state is less than the number of atoms in the lower energy state. For the production of LASER number of stimulated emission must be more when compared to induced absorption and spontaneous emission. This is possible only if the number of atoms in the higher energy state is more than the number of atoms in the lower energy state and is called population inversion. The means of achieving population inversion by supplying energy from a suitable source is called Pumping. In addition, to have more stimulated emissions, the life time of atoms in the excited state must be longer. Thus the essential conditions for population inversion are

1. Higher energy state should possess a longer life time.
2. The number of atoms in the higher energy state must be greater than the number of atoms in the lower energy state.

### 1.5.2 meta-stable state

The life time of an energy level is of the order of  $10^{-8}$  second. If an atom possesses unusual longer life time in an energy state such a state is referred to as a meta-stable state. Usually the life time of meta-stable state varies from  $10^{-2}$ s to  $10^{-3}$ s. Population inversion could be achieved with the help of three energy states with one of them a meta-stable state and is as shown in the figure 1.5. The population inversion is achieved between the state  $E_2$  and  $E_1$  as state  $E_2$  is a meta-stable state.

**Note :** The principles of Laser are

1. Stimulated Emission
2. Population Inversion
3. meta-stable State






Figure 1.5: Population inversion,  $E_2$  is meta-stable state

## 1.6 Requisites of a LASER system

The three requisites of a LASER system are,

1. Excitation source for pumping action
2. Active medium that supports meta-stable states
3. LASER cavity

### 1.6.1 Energy Source or Pumping Mechanism

In order to achieve population inversion more and more atoms are to be moved to higher energy state and is called pumping. This is achieved by supplying suitable energy using an energy source. If optical energy is used then the pumping is called optical pumping and if electrical energy is used then the pumping is called electrical pumping.

### 1.6.2 Active medium

Population inversion occurs at certain stage in the active medium due to the absorption of energy. The active medium supports meta-stable states. After this stage the active medium is capable of emitting LASER light.

### 1.6.3 Resonant cavity (or) LASER cavity

The LASER Cavity consists of an active medium bound between two highly parallel mirrors. The reflection of photons from the mirrors results in multiple traverse of photons through the active medium inducing more and more stimulated emissions. Thus amplification of light is achieved. This also helps to tap certain permissible part of LASER energy from the active medium. The cavity resonates and the output will be maximum when the distance  $L$  between the mirrors is equal to an integral multiple of  $\frac{\lambda}{2}$ . Here  $\lambda$  is the wavelength of incident suitable radiation. the length of the LASER cavity is expressed as

$$L = \frac{n \lambda}{2} \quad (1.12)$$

## 1.7 Semiconductor LASER or Diode LASER

### Introduction

Semiconductor diode LASER is an LED with heavily doped P and N sections. First semiconductor LASER was fabricated in 1962 using  $Ga - As$  by Hall with his co-workers. It is a low cost and high efficiency LASER.





Figure 1.6: Semiconductor Diode LASER

### Construction

#### Construction

The  $Ga - As$  LASER diode belongs to direct band gap semiconductors. The  $n$ -section is derived by doping the substrate with *Tellurium* and  $p$ -section is derived by doping the substrate with *Zinc*. The diode used is in the form of a cube with dimension 0.4 mm. The depletion region is of thickness 0.1 micrometer and lies horizontal as shown in the figure 1.6. The current is passed through the ohmic contacts provided to the top and bottom faces. The front and back faces are polished and made highly parallel to each other to have a LASER cavity. The other two faces are roughened.



### Working

The Diode is forward biased using an external source. Therefore electrons and holes flow across junction. Hence



## GURU NANAK DEV ENGINEERING COLLEGE, BIDAR

### DEPARTMENT OF APPLIED SCIENCES & HUMANITIES

the current flows through the diode. When a hole meets an electron it recombines with electron emitting a photon. This could be considered as the transition of electron from conduction band to valance band. When the current is low spontaneous emission is predominant. If the current is sufficiently high population inversion is achieved. The photons liberated initially due to spontaneous emissions induce further stimulated emissions. The LASER cavity helps in the amplification of light. Finally this results in an avalanche of photons and hence the LASER action is achieved. If the GaAs semiconductor is used then the wavelength of the LASER emitted is 840nm.

#### Advantages

1. It has excellent efficiency
2. The output can be modulated
3. It produces both continuous wave output or pulsed output.
4. It is highly economical

#### Applications

1. It is used in optical fiber communication.
2. It is used in commercial CD recording and reading.
3. It is used in Barcode Reader, Laser printing and Laser Cooling.

## 1.8 Applications of LASER

LASER has wide range of applications pertaining all disciplines of engineering. Here in the syllabus only two applications are discussed relevant to computing.

### 1.8.1 LASER Barcode Reader




Figure 1.7: Barcode Reader



Figure 1.8: barcode

A barcode is a printed series of parallel bars or lines of varying width that is used for entering data into a computer system.

A barcode scanner/reader is a device with lights, lenses, and a sensor that decodes and captures the information contained in barcodes. Laser scanners use a laser beam as a light source and typically employ oscillating mirrors or rotating prisms to scan the laser beam back and forth across the barcode. A photodiode then measures the reflected light from the barcode. An analog signal is created from the photodiode, and is then converted into a digital signal.

### 1.8.2 LASER Printer

Laser printers were invented at XEROX in 1969 by researcher Gary Starkweather. Laser Printers are digital printing devices that are used to create high quality text and graphics on plain paper. A Diode Laser is used in the process of printing in LASER Printer.

#### Construction




Figure 1.9: Laser Printer Schematic

#### Working Principle

1. A laser beam projects an image of the page to be printed onto an electrically charged rotating Photo sensitive drum coated with selenium.
2. Photo conductivity allows charge to leak away from the areas which are exposed to light and the area gets positively charged.
3. Toner particles are then electrostatically picked up by the drum's charged areas, which have been exposed to light.
4. The drum then prints the image onto paper by direct contact and heat, which fuses the ink to the paper.



# GURU NANAK DEV ENGINEERING COLLEGE, BIDAR

## DEPARTMENT OF APPLIED SCIENCES & HUMANITIES

### Advantages

1. Laser printers are generally quiet and fast.
2. Laser printers can produce high quality output on ordinary papers.
3. The cost per page of toner cartridges is lower than other printers.

### Disadvantages

1. The initial cost of laser printers can be high.
2. Laser printers are more expensive than dot-matrix printers and ink-jet printers

### 1.8.3 LASER Cooling

**Principle of LASER Cooling** Laser cooling is the use of dissipative light forces for reducing the random motion and thus the temperature of small particles, typically atoms or ions. Depending on the mechanism used, the temperature achieved can be in the millikelvin, microkelvin, or even nanokelvin regime.




Figure 1.10: Laser Cooling

If an atom is traveling toward a laser beam and absorbs a photon from the laser, it will be slowed by the fact that the photon has momentum  $p = \frac{E}{c} = \frac{h}{\lambda}$ . It would take a large number of such absorptions to cool the atoms to near 0K. The following are the types of laser cooling

- Doppler Cooling.
- Sisyphous Cooling.

### 1.9 Model Questions

1. What is LASER? Enumerate the Characteristics of a LASER Beam.
2. Discuss the three possible ways through which radiation and matter interaction can take place.

3. Explain the terms, (i) Induced absorption, (ii) Spontaneous emission, (iii) Stimulated emission, (iv) Population inversion, (v) Meta-stable state & (vi) Resonant cavity.
4. Explain the rates of absorption and emission and hence derive an expression for energy density using Einstein's A and B coefficients.
5. Explain requisites of LASER system.
6. What is Semiconductor LASER? Describe with energy band diagram the construction & working of Semiconductor diode LASER along with applications.
7. Discuss the working of LASER barcode reader.
8. With the help of a sketch describe the principle, construction and working of the LASER Printer.
9. Explain LASER Cooling and its application.

### 1.10 Numerical Problems

1. Find the ratio of population of two energy levels in a LASER if the transition between them produces light of wavelength  $6493 \text{ \AA}$ , assuming the ambient temperature at  $27^\circ\text{C}$ .
2. Find the ratio of population of two energy levels in a medium at thermal equilibrium, if the wavelength of light emitted at  $291 \text{ K}$  is  $6928 \text{ \AA}$ .
3. The ratio of population of two energy levels out of which one corresponds to metastable state is  $1.059 \times 10^{-30}$ . Find the wavelength of light emitted at  $330 \text{ K}$ .
4. Find the ratio of population of two energy levels in a medium at thermal equilibrium, if the wavelength of light emitted at  $300 \text{ K}$  is  $10 \mu\text{m}$ . Also find the effective temperature when energy levels are equally populated.
5. The average power output of a LASER beam of wavelength  $6500 \text{ \AA}$  is  $10 \text{ mW}$ . Find the number of photons emitted per second by the LASER source.
6. The average power of a LASER beam of wavelength  $6328 \text{ \AA}$  is  $5 \text{ mW}$ . Find the number of photons emitted per second by the LASER source.
7. A pulsed LASER has an average power output  $1.5 \text{ mW}$  per pulse and pulse duration is  $20 \text{ ns}$ . The number of photons emitted per pulse is estimated to be  $1.047 \times 10^8$ . Find the wavelength of the emitted LASER.
8. A pulsed LASER with power  $1 \text{ mW}$  lasts for  $10 \text{ ns}$ . If the number of photons emitted per pulse is  $5 \times 10^7$ . Calculate the wavelength of LASER.





**GURU NANAK DEV ENGINEERING COLLEGE, BIDAR**  
**DEPARTMENT OF APPLIED SCIENCES & HUMANITIES**

9. A Ruby LASER emits a pulse of 20 ns duration with average power per pulse being 100 kW. If the number of photons in each pulse is  $6.981 \times 10^{15}$ , calculate the wavelength of photons.
10. In a LASER system when the energy difference between two energy levels is  $2 \times 10^{-19}$  J, the average power output of LASER beam is found to be 4 mW. Calculate number of photons emitted per second.



## Chapter 2

# Optical Fibers

## 2.1 Introduction

Optical fibers are the wires and strands made of transparent dielectrics which guide light over longer distances using the phenomenon of **Total Internal Reflection**. Many optical fibers are bundled together and are given a protective layer of covering using an insulating material. This bundle is called Optical Fiber Cable or Fiber Bundle (Bundle Fiber).

**Construction:** The sectional view of a typical optical fiber is as shown in the figure. It has three regions named Core, Cladding and Sheath.

1. The innermost light guiding region is called Core.
2. The layer covering core and helps in total internal reflection of light is called Cladding or Clad.
3. The outermost protective layer is called Sheath (Coating). The sheath protects the fiber from mechanical stress and chemical reactions.

The optical fiber is designed to support total internal reflection and hence the RI of core  $n_1$  is made greater than the RI of cladding  $n_2$ . A typical fiber will be of the order of few microns.




Figure 2.1: Optical fiber construction

## 2.2 Total Internal Reflection

Consider a ray of light moving from a denser medium to rarer medium. As a result the incident ray of light bends away from the normal. Hence the angle of refraction is greater than the angle of incidence. As the angle of incidence increases the angle of refraction also increases. For a particular angle of incidence  $\theta_c$  the refracted ray grazes the interface separating the two media. The corresponding angle of incidence  $\theta_c$  is called Critical Angle. If the angle of incidence is greater than the critical angle then all the light is turned back into the same medium and is called Total Internal Reflection.




Figure 2.2: Total Internal Reflection

According to Snell's law

$$n_1 \sin \theta_1 = n_2 \sin \theta_2$$

$$\text{when } \theta_1 = \theta_c \text{ then, } \theta_2 = 90^\circ$$

$$n_1 \sin \theta_c = n_2 \sin 90^\circ$$

$$\sin \theta_c = \frac{n_2}{n_1}$$

$$\theta_c = \sin^{-1} \left( \frac{n_2}{n_1} \right) \quad (2.1)$$

## 2.3 Angle of acceptance and Numerical aperture

Acceptance angle ( $\theta_0$ ) is the maximum angle of incidence with which the ray is sent into the fiber core which allows

the incident light to be guided by the core. It is also called as waveguide acceptance angle or acceptance cone half angle.

In optics, the numerical aperture (NA) of an optical fiber is a dimensionless number that characterizes the range of angles over which the fiber can accept light. Numerical aperture represents the light gathering capability of optical fiber and it is given by  $NA = \sin\theta_0$ .

### 2.3.1 Condition for propagation




Figure 2.3: Ray propagation in the fiber

Consider an optical fiber with core made of refractive index  $n_1$  & cladding made of material refractive index  $n_2$ . Let  $n_0$  be the refractive index of the surrounding medium. Let a ray of light  $AO$  entering into core at an angle of incidence  $\theta_0$  w.r.t fiber axis. Then it is refracted along  $OB$  at an angle  $\theta_1$  & meet core-cladding interface at critical angle of incidence ( $\theta_c = 90 - \theta_1$ ). Then the refracted ray grazes along  $BC$ . On applying Snell's law at O, we get

$$\begin{aligned} n_0 \sin\theta_0 &= n_1 \sin\theta_1 \\ \therefore \sin\theta_0 &= \frac{n_1}{n_0} \sin\theta_1 \end{aligned} \quad (2.2)$$

On applying Snell's law at point B, we get

$$\begin{aligned} n_1 \sin(90^\circ - \theta_1) &= n_2 \sin 90^\circ \\ n_1 \cos\theta_1 &= n_2 \\ \therefore \cos\theta_1 &= \frac{n_2}{n_1} \end{aligned} \quad (2.3)$$

**From trigonometric identity**

$$\begin{aligned} \sin^2\theta_1 + \cos^2\theta_1 &= 1 \\ \sin\theta_1 &= \sqrt{1 - \cos^2\theta_1} \end{aligned}$$

using equation 1.25

$$\begin{aligned} \sin\theta_1 &= \sqrt{1 - \left(\frac{n_2}{n_1}\right)^2} \\ \sin\theta_1 &= \sqrt{\frac{n_1^2 - n_2^2}{n_1^2}} \end{aligned}$$

$$\sin\theta_1 = \frac{1}{n_1} \sqrt{n_1^2 - n_2^2} \quad (2.4)$$

use equation (1.26) in equation (1.24) we have,

$$\begin{aligned} \sin\theta_0 &= \frac{n_1}{n_0} \frac{1}{n_1} \sqrt{n_1^2 - n_2^2} \\ \sin\theta_0 &= \frac{1}{n_0} \sqrt{n_1^2 - n_2^2} \end{aligned} \quad (2.5)$$

Numerical aperture  $N.A = \sin\theta_0$

$$N.A = \frac{1}{n_0} \sqrt{n_1^2 - n_2^2} \quad (2.6)$$

If the fiber is in air  $n_0 = 1$  then,

$$N.A = \sin\theta_0 = \sqrt{n_1^2 - n_2^2} \quad (2.7)$$

Light is transmitted through the fiber only when

$$\theta_i \leq \theta_0 \quad (2.8)$$

$$\sin\theta_i \leq \sin\theta_0 \quad (2.9)$$

$$\sin\theta_i \leq \sqrt{n_1^2 - n_2^2} \quad (2.10)$$

$$\sin\theta_i \leq N.A \quad (2.11)$$

This is the condition for propagation. Light will be transmitted through the optical fiber with multiple total internal reflections when the above condition is satisfied.

## 2.4 Modes of propagation

Though optical fiber should support any numbers of rays for propagation practically. But it is found that the optical fiber allows only a certain restricted number of rays for propagation. The maximum number of rays or paths supported by the fiber for the propagation of light is called *Modes of propagation*. Based on the modes of propagation fibers are classified into Single mode and Multi-mode fibers.

## 2.5 RI Profile

The RI profile is a plot of variation of RI of the fiber with respect to radial distance from the axis of an optical fiber. Based on the RI profile fibers are classified into Step index and Graded index fibers. In case of Step index fibers RI of the core is constant. In case of Graded index fibers the RI decreases radially outwards.




Figure 2.4: RI profile of step index fiber

### 2.5.1 Types of optical fibers

In any optical fiber, the whole material of the cladding has a uniform refractive index value. But the refractive index of the core material may either remain constant or subjected to variation in a particular pattern. The curve which represents the variation of refractive index with respect the radial distance from the axis of the fiber is called the *refractive index profile*. The optical fibers are classified under 3 categories,

1. Step index single mode fiber
2. Step index multi-mode fiber
3. Graded index multi-mode fiber

This classification is done depending on the refractive index profile, and the number of modes that the fiber can guide.

#### Step index single mode fiber

A single mode step index fiber consists of a very fine thin core of uniform RI surrounded by Cladding of RI lower than that of Core. Since there is abrupt change in the RI of Core and Cladding at the interface it is called step index fiber. Since the Core size is small the Numerical aperture is also small and hence support single mode. They accept light from LASER source. Splicing is difficult. They are used in submarine cables.




Figure 2.5: Step index single mode fiber

#### Step index multi-mode fiber

This is similar to single mode step index fiber with the exception that it has a larger core diameter. The core diameter

is very large as compared to single mode optical fiber. A typical multi-mode step index fiber is as shown in figure. The numerical aperture is large because of large core size and thus support multi-modes. They accept light from both LASER as well as from LED. They are used in data links.




Figure 2.6: Step index multi-mode fiber

#### Graded index multi-mode fiber

A multi-mode fiber has concentric layers of RI is called GRIN fiber. It means the R I of the Core varies with distance from the fiber axis. The RI is maximum at the center and decreases with radial distance towards to core-cladding interface. The R I profile is as shown in fig. In GRIN fibers the acceptance angle and numerical aperture diminish with radial distance. The light transmission is as shown above. They accept light from both LASER as well as from LED. They are used for medium distance communication for example telephone link between central offices.




Figure 2.7: Graded index multimode fiber

## 2.6 Attenuation

The optical energy (signal) passing through the optical fiber gets reduced progressively. This is due to attenuation. It is also called the fiber loss or significant loss. The attenuation is measured in terms of attenuation co-efficient. The attenuation co-efficient  $\alpha$  is defined as the ratio of optical power output to the optical power input for a fiber of length L and for a given wavelength of propagating light. It is expressed in dB/km. Attenuation co-efficient is given by

$$\alpha = \frac{-10}{L} \log_{10} \left( \frac{P_{out}}{P_{in}} \right) \text{ dB/km} \quad (2.12)$$





# GURU NANAK DEV ENGINEERING COLLEGE, BIDAR

## DEPARTMENT OF APPLIED SCIENCES & HUMANITIES

Here  $L$  is the length of the cable in  $km$ ,  $P_{in}$  is Power of optical signal at launching end (input power) &  $P_{out}$  is Power of optical signal at receiving end (output power)

The attenuation in fibers gives is due to the following three losses

1. Absorption losses
2. Scattering loss (due to Rayleigh Scattering)
3. Geometric Effects (Radiation losses)

### 2.6.1 Absorption loss

In this type of loss, the loss of signal power occurs due to absorption of photons associated with the signal. Photons are absorbed either by impurities in the glass fiber or by pure glass material itself. Absorption loss is wavelength dependent. Thus absorption loss is classified in to two types.

**Extrinsic absorption :** Extrinsic loss in an optical fiber is due to the absorption of light by the impurities such as hydroxide ions and transition metal ions such as iron, chromium, cobalt and copper.

**Intrinsic absorption** Intrinsic loss in fiber is due to the absorption of light by the material of the fiber glass itself. The intrinsic losses are insignificant.

### 2.6.2 Scattering loss

Light traveling through the core can get scattered by impurities or small regions with sudden change in refractive index. Rayleigh scattering varies as  $\alpha = \frac{1}{\lambda^4}$  and leads to significant power loss at smaller wavelengths. The scattering results in loss of photons. Rayleigh scattering is responsible for maximum losses in optical fibers.

### 2.6.3 Geometric effects

These may occur due to manufacturing defects like irregularities in fiber dimensions during drawing process or during coating, cabling or insulation processes. The microscopic bends are the bends with radii greater than fiber diameter. The microscopic bends couple light between the various guided modes of the fiber and some of them then leak through the fiber.

## 2.7 Applications of Optical Fibers

### 2.7.1 Fiber Optic Networking

#### Local Area Network

A Local Area Network (LAN) is a type of computer network that interconnects multiple computers and computer-

driven devices in a particular physical location. Traditionally copper coaxial cables are used for LAN.




Figure 2.8: Fiber Optic LAN

### Abbreviations

1. PON - Passive Optical Network
2. ONT - Optical Network Terminal
3. ODN - Optical Distribution Network
4. OLT - Optical Line Terminal
5. ONU - Optical Network Unit

### Passive Optical LAN

A passive optical network refers to a fiber-optic network utilizing a point-to-multipoint topology and optical splitters to deliver data from a single transmission point to multiple user endpoints. Passive here refers to the unpowered condition of the fiber and splitting/combining components. Passive optical LANs are built entirely using Optical fiber cables. The passive optical LAN works on the concept of optical network terminals (ONT) and passive optical splitters. Network switches act as passive splitters and the commercial media converters act as optical network terminals in a real-time application of passive optical LAN.

### Advantages

1. High speeds and bandwidth
2. Longer distances are possible
3. Less chance of errors

### 2.7.2 Point to point communication using Optical Fibers

In an optical fiber communication system, the input signals (audio, video or other digital data) are used to modulate light from a source like a LED or a semiconductor LASER and is transmitted through optical fiber. At the



## GURU NANAK DEV ENGINEERING COLLEGE, BIDAR

### DEPARTMENT OF APPLIED SCIENCES & HUMANITIES

receiving end the signal is demodulated to reproduce the input signal. If data transfer takes place between only two devices then, it is called point to point communication.




Figure 2.9: Point to point fiber optic communication system

**Optical fiber communication process :** The communication using Optical fiber is as follows. First voice is converted into electrical signal using a transducer. It is digitized using a Coder. The digitized signal, which carries the voice information, is fed to an optical transmitter. The light source in optical transmitter (LED or LASER Diode) emits modulated light, which is transmitted through the optical fiber. At the other end the modulated light signal is detected by a photo detector and is decoded using a decoder. Finally the information is converted into analog electrical signal and is fed to a loud speaker, which converts the signal to voice (sound).

#### Advantages

1. Optical fibers can carry very large amounts of information in either digital or analog form.
2. The raw material for optical fiber is of low cost and abundant.
3. It has low cost /meter/ channel
4. Cables are very compact
5. Signals are protected from radiation from lightning or sparking
6. There is no energy radiation from fiber
7. No sparks are generated

#### Disadvantages

1. The optical connectors are very costly
2. Maintenance cost is high
3. They cannot be bent too sharply
4. They under go structural changes with temperature

## 2.8 Model Questions

1. Define the terms: (i) angle of acceptance, (ii) numerical aperture, (iii) modes of propagation & (iv) refractive index profile.
2. Obtain an expression for numerical aperture and arrive at the condition for propagation.
3. Explain modes of propagation and RI profile.
4. What is attenuation? Explain the factors contributing to the fiber loss.
5. Discuss the types of optical fibers based on modes of propagation and RI profile.
6. Explain attenuation along with the expression for attenuation co-efficient and also discuss the types of fiber losses.
7. Explain the Fiber Optic Networking and mention its advantages.
8. Discuss point to point optical fiber communication system and mention its advantages over the conventional communication system.
9. Discuss the advantages and disadvantages of an optical communication.

## 2.9 Numerical Problems

1. Calculate the numerical aperture and angle of acceptance for an optical fiber having refractive indices 1.563 and 1.498 for core and cladding respectively.
2. The refractive indices of the core and cladding of a step index optical fiber are 1.45 and 1.4 respectively and its core diameter is  $45\mu\text{m}$ . Calculate its fractional refractive index change and numerical aperture.
3. Calculate numerical aperture, acceptance angle and critical angle of a fiber having a core RI 1.50 and cladding RI 1.45.
4. An optical fiber has a numerical aperture of 0.32. The refractive index of cladding is 1.48. Calculate the refractive index of the core, the acceptance angle of the fiber and the fractional index change.
5. An optical signal propagating in a fiber retains 85% of input power after traveling a distance of 500 m in the fiber. Calculate the attenuation coefficient.
6. An optical fiber has core RI 1.5 and RI of cladding is 3% less than the core index. Calculate the numerical aperture, angle of acceptance critical angle.



**GURU NANAK DEV ENGINEERING COLLEGE, BIDAR**  
**DEPARTMENT OF APPLIED SCIENCES & HUMANITIES**

7. The numerical aperture of an optical fiber is 0.2 when surround by air. Determine the RI of its core, given the RI of the cladding is 1.59. Also find the acceptance angle when the fiber is in water of RI 1.33.
8. The angle of acceptance of an optical fiber is  $30^\circ$  when kept in air. Find the angle of acceptance when it is in medium of refractive index 1.33.
9. An optical fiber of 600 m long has input power of 120 mW which emerges out with power of 90 mW. Find attenuation in fiber.
10. The attenuation of light in an optical fiber is 3.6 dB/km. What fraction of its initial intensity is remains after i) 1 km and ii) 3 km ?
11. The attenuation of light in an optical fiber is 2.2 dB/km. What fraction of its initial intensity is remains after i) 2 km and ii) 6 km ?